A GUIDE FOR CLEANING YOUR PC AND PRINTER

HP Inc. is committed to providing productive and innovative solutions that support the wellbeing of all. We're sharing these tips to effectively clean your devices in an effort to maintain a more hygienic work and entertainment environment.

The recommended disinfectant is an alcohol based solution consisting of:




70% isopropyl alcohol

30% water

Follow these steps:

Use disposable gloves



Turn off the device and ensure to disconnect the power or remove batteries



Disconnect all external devices



Dampen a microfiber handkerchief with the alcohol based solution



Do not spray any liquid directly onto your device




Carefully clean all external surfaces. Do not allow any water to drip onto the keyboard, screen or USB port



Start with your screen or control panel and end with the cables



Gently wipe in the same direction, top to bottom



Make sure all surfaces are dry before powering on your device

After disinfecting, clean the glass of the equipment again with a glass cleaner



Dispose of the gloves after each cleaning



Wash your hands immediately afterwards

